



MP 84

Rechargeable manicure/pedicure set with a practical charging and storage case



With a practical charging and storage case



Powerful Lithium ion battery



With 10 high-quality attachments for nail and skin care



For well-cared hands and feet

With bright LED light

Ergonomic design prevents slipping during treatment

10 high-quality sapphire and felt attachments:

1. Sapphire Cone: Suitable for removing dry skin and softening calluses on the sole and heel.
2. Fine-Grain Sapphire Wheel: Suitable for filing nails to reduce length.
3. Coarse-Grain Sapphire Wheel: Suitable for filing thicker nails to reduce length.
4. Crystal Callus File: Suitable for removing thick hard skin or large calluses on the sole of the foot and heel.
5. Flame-Shape Cutter: Suitable for removing ingrowing nails.
6. Cylindrical Cutter: Suitable for smoothing rough and ridged toenail surfaces.
7. Felt Cone: Suitable for smoothing and buffing nail tips after filing and for cleaning the surface of the nails.
8. Round Sapphire Cutter: Suitable for removing corns.
9. Nail Cutter: Suitable for exposing ingrown nails and removing dead nail parts.
10. Sapphire Callus File: For removing calluses on the soles of the feet and heel. This attachment is intended for application on large areas.

Incl. protective cap for nail dust

With lithium ion battery for 2 hours operation time; charging time approx. 3 hours

3 speeds

Speed: 3,200 / 3,800 / 4,400 U/min. ±15%

Magic LED display appears only during operation

With Micro USB cable

Power supply: Input: 5.0 V $\overline{\text{---}}$ 1.0 A; 5.0 W

Case dimensions: 223 x 74 x 67.5 mm

Device dimensions: 155 x 37.4 x 38.3 mm

Case weight including accessories: approx. 323 g

Device weight: approx. 135 g

3 year guarantee

Sales unit: 3 / Shipping carton: 4 x 3

EAN-Nr.: 4211125 57002 6

Art.-Nr.: 570.02

