



UB 86 XXL Komfort Doppel-Wärmeunterbett

Komfortables Wärme-Unterbett mit Teddy-Oberseite
Separat einstellbare Temperaturzonen für Körper und Füße

Je Zone 9 Temperaturstufen

Innovative Schalter mit beleuchteten LCD-Displays

Individuell einstellbarer Timer (1 Std.-Schritte)

EcoControl: Verbrauchsanzeige in kWh

Schnellheizung

Vorwärmzeit ca. 15 min.

BSS (Beurer Sicherheitssystem)

Rückschaltautomatik nach 3 Std. von Temperaturstufe 7, 8 und 9 auf Temperaturstufe 6

Größe ca. 150 cm (Länge) x 160 cm (Breite)

Anti-Allergie-Temperaturstufe

Abnehmbare Schalter

Maschinenwaschbar bis 30°C

Öko-Tex

Die bei diesem Gerät eingesetzten Textilien erfüllen die hohen humanökologischen Anforderungen des Öko-Tex Standards 100, wie durch das Forschungsinstitut Hohenstein nachgewiesen.

2 x 60 Watt / Anheizphase 2 x 75 Watt

5 Jahre Garantie

VE: 4 / Transportkarton:

EAN-Nr.: 4211125 31912 0

Art-Nr.: 319.12

UB 86 XXL Comfort heated underblanket for double beds

Comfort heated underblanket with soft fleecy upper

Separately adjustable temperature zones for body and feet

9 temperature settings for each zone

Innovative switches with illuminated LCD displays

Individually adjustable timer (1 hour intervals)

EcoControl: Consumption indicator in kWh

Rapid heat up

Pre-heating time approx. 15 min.

BSS (Beurer Safety System)

Automatic switch down from heat settings 7, 8 and 9 to setting 6 after 3 hours

Size approx. 150 cm (length) x 160 cm (width)

Anti-Allergy-temperature setting

Detachable control units

Machine washable up to 30°C

Oeko-Tex

The textiles used for this device meet the stringent human ecological requirements of Oeko-Tex Standard 100, as verified by Hohenstein Research Institute.

2 x 60 Watts / Preheating 2 x 75 Watts

5 year guarantee

Sales unit: 4 / Shipping carton:

EAN no.: 4211125 31912 0

Item no.: 319.12